


KIDSAW®

PUZZLE FURNITURE




MY FIRST JCB BEDSIDE ASSEMBLY INSTRUCTION

WWW.KIDSAW.CO.UK


A MEMBER OF
ACID
ANTI COPYING IN DESIGN

All copyright, design rights and intellectual property rights existing in our designs and products and in the images, text and design of our website / marketing material are and will remain the property of Kidsaw Limited. We will treat any infringement of these rights seriously."


A) List of Parts




Side Panel x 2




Front Panel x 1



Back Panel x 1



Base Panels x 1




Top Panels x 1




Braces x 2

B) Steps to Assembly


ADULT ASSEMBLY REQUIRED



Step 1 –




Step 2 –




Step 3 –

B) Steps to Assembly

ADULT ASSEMBLY REQUIRED



Step 4 –



Assembly complete

ANY QUESTIONS? GIVE US A CALL DIRECT

KIDSAW PUZZLE FURNITURE is designed and distributed by kidsaw limited,UK.

For any queries, missing parts, comments or suggestions on the product, please call our customer support at +44 (0) 116 2519551 during Monday - Friday 9:00 a.m. to 4:30 p.m. ; Or, mail to 47-55 Northgate Street, Leicester, LE3 5BZ; Or, email to support@kidsaw.co.uk.

Thank you for purchasing KIDSAW PUZZLE FURNITURE

KIDSAW
PUZZLE FURNITURE

JCBCB - ASSEMBLY INSTRUCTION - 4