


# KIDS SAW®

PUZZLE FURNITURE



## My FIRST JCB BOOKCASE ASSEMBLY INSTRUCTION


[WWW.KIDSAW.CO.UK](http://WWW.KIDSAW.CO.UK)

A MEMBER OF  
**ACID**  
ANTI COPYING IN DESIGN


*All copyright, design rights and intellectual property rights existing in our designs and products and in the images, text and design of our website / marketing material are and will remain the property of Kidsaw Limited. We will treat any infringement of these rights seriously.*

# Steps to Assembly

## ADULT ASSEMBLY REQUIRED



x 6



x 15

ANY QUESTIONS? GIVE US A CALL DIRECT

KIDSAW PUZZLE FURNITURE is designed and distributed by kidsaw limited,UK.

For any queries, missing parts, comments or suggestions on the product, please call our customer support at +44 (0) 116 2519551 during Monday - Friday 9:00 a.m. to 4:30 p.m. ; Or, mail to 47-55 Northgate Street, Leicester, LE3 5BZ; Or, email to support@kidsaw.co.uk.

Thank you for purchasing KIDSAW PUZZLE FURNITURE

